

HINKLEY

HIRO

QUICK PAIRING GUIDE



STEP 1: Disconnect power to all fans at the breaker or wall switch.

NOTE: Turning the power off with the remote or wall control is not sufficient. Power must be cut to the fans via breaker or wall switch. For multiple fans on the same circuit, the power must be disconnected at the canopy connection for the fan(s) NOT being paired.

HOW TO PAIR YOUR HIRO REMOTE

STEP 2: Restore power ONLY to the fan being paired.

STEP 3: Within 60 seconds of power being restored, press the **FAN ON/OFF** button for 3 seconds and hold.

NOTE: Fan will start on low speed and the light will turn on. Light will flash twice and the fan will turn off. This indicates successful pairing.

DELETING UNWANTED HIRO REMOTE PAIRINGS

STEP 2: Restore power ONLY to the fan being corrected to a single HIRO pairing.

STEP 3: Within 60 seconds of power being restored, press the **FAN ON/OFF** button for 8 seconds and hold.

NOTE: Light will flash twice and an audible “beep” will sound three times (6 speed DC fans). Now the fan should only respond to the HIRO control used to perform the 8 second pairing.

FOR MORE INFORMATION ON THE HIRO REMOTE
VISIT [HINKLEY.COM/FANS](https://www.hinkley.com/fans) OR CALL 1(800) 446-5539
FOR TROUBLESHOOTING NEEDS

